


fullwat[®]

professional *solutions*

PDA5500-STATION



pure sine wave



Power DC-AC Inverter

Multi-function INVERTER/CHARGER:

inverter + MPPT solar charger + battery charger

1. INTRODUCTION

This is a multi-function inverter/charger, combining functions of inverter, MPPT solar charger and battery charger to offer uninterruptible power support with portable size. Its comprehensive LCD display offers user-configurable and easy-accessible button operation such as battery charging current, AC/solar charger priority, and acceptable input voltage based on different applications.

2. FEATURES

- Pure sine wave output.
- Output power factor 1.0 .
- Programmable supply priority for PV ,battery or Grid.
- User-adjustable charge current and voltage.
- Wide PV input range (120Vdc-500Vdc), 110A MPPT SCC.
- Working without batteries in sunny day.
- WiFi monitoring function (optional).
- Anti-dusk kit for harsh environment (optional).
- LCD remote control with 10 meters wire (optional).
- PV and electricity complementary.
- Use with lithium batteries.
- MPPT charging regulation mode.

3. BASIC SYSTEM ARCHITECTURE

The following illustration shows basic application for this inverter/charger. It also includes following devices to have a complete running system:

- Generator or Utility.
- PV modules (option).

Consult with your system integrator for other possible system architectures depending on your requirements.

This inverter can power all kinds of appliances in home or office environment, including motor-type appliances such as tube light, fan, refrigerator and air conditioner.






Fig. 1 - Hybrid power system

4. PRODUCT OVERVIEW



Indication

- | | | |
|----------------------|-----------------------|----------------------------------|
| ① LCD Display | ⑤ Function buttons | ⑨ PV Input |
| ② Status indicator | ⑥ Power ON/OFF switch | ⑩ Battery input |
| ③ Charging indicator | ⑦ AC input | ⑪ Circuit breaker |
| ④ Fault indicator | ⑧ AC output | ⑫ RS485/RS232 communication port |

5. INSTALLATION


5.1 Unpacking and Inspection

Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. You should have received the following items inside of package:

- The unit x 1
- User manual x 1
- Communication cable x 1

5.2 Preparation

Before connecting all wirings, please take off bottom cover by removing two screws as shown below.




5.3 Mounting the unit

Consider the following points before selecting where to install:

- Do not mount the inverter on flammable construction materials.
- Mount on a solid surface
- Install this inverter at eye level in order to allow the LCD display to be read at all times.
- The ambient temperature should be between 0°C and 55°C to ensure optimal operation.
- The recommended installation position is to be adhered to the wall vertically.
- Be sure to keep other objects and surfaces as shown in the right diagram to guarantee sufficient heat dissipation and to have enough space for removing wires.

⚠ SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.

Install the unit by screwing three screws. It's recommended to use M4 or M5.




5.4 Battery connection

Caution:


For safety operation and regulation compliance, it's requested to install a separate DC over-current protector or disconnect device between battery and inverter. It may not be requested to have a disconnect device in some applications, however, it's still requested to have over-current protection installed. Please refer to typical amperage in below table as required fuse or breaker size.

WARNING! All wiring must be performed by a qualified personnel.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for battery connection. To reduce risk of injury, please use the proper recommended cable and terminal size as below.



Ring terminal




Recommended battery cable and terminal size:

| Model | Input voltage | Typical amperage | Battery capacity | Wire size | Ring terminal | | | Torque value |
|-----------------|---------------|------------------|------------------|-----------|-----------------------|------------|--------|--------------|
| | | | | | Cable mm ² | Dimensions | | |
| | | | | | | D (mm) | L (mm) | |
| PDA5500-STATION | 48V | 115A | 200AH | 1*4AWG | 22 | 6.4 | 33.2 | 2~3 Nm |
| | | | | 2*8AWG | 14 | 6.4 | 29.2 | |

Please follow below steps to implement battery connection:

1. Assemble battery ring terminal based on recommended battery cable and terminal size.
2. Connect all battery packs as units requires.
Note: Please only use sealed lead acid battery or sealed GEL/AGM lead-acid battery.
3. Insert the ring terminal of battery cable flatly into battery connector of inverter and make sure the bolts are tightened with torque of 2-3 Nm. Make sure polarity at both the battery and the inverter/charge is correctly connected and ring terminals are tightly screwed to the battery terminals.



Warning: Shock Hazard

Installation must be performed with care due to high battery voltage in series.

Caution!! Do not place anything between the flat part of the inverter terminal and the ring terminal. Otherwise, overheating may occur.

Caution!! Do not apply anti-oxidant substance on the terminals before terminals are connected tightly.

Caution!! Before making the final DC connection or closing DC breaker/disconnector, be sure positive (+) must be connected to positive (+) and negative (-) must be connected to negative (-).

5.5 AC Input/Output connection

Caution!! Before connecting to AC input power source, please install a **separate** AC breaker between inverter and AC input power source. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current of AC input. The recommended spec of AC breaker is 50A for PDA5500-STATION.

Caution!! There are two terminal blocks with "IN" and "OUT" markings. Please do NOT mis-connect input and output connectors.

WARNING! All wiring must be performed by a qualified personnel.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable size as below.

Suggested cable requirement for AC wires.

| Model | Gauge | Torque value |
|-----------------|-------|--------------|
| PDA5500-STATION | 8AWG | 1.4~1.6 Nm |


Please follow below steps to implement AC input/output connection:

1. Before making AC input/output connection, be sure to open DC protector or disconnecter first.
2. Remove insulation sleeve 10mm for six conductors. And shorten phase L and neutral conductor N 3mm.
3. Insert AC input wires according to polarities indicated on terminal block and tighten the terminal screws. Be sure to connect PE protective conductor (⊕) first.

- ⊕ → Ground (yellow-green)
- L → LINE (brown or black)
- N → Neutral (blue)


Warning:

Be sure that AC power source is disconnected before attempting to hardwire it to the unit.



4. Then, insert AC input wires according to polarities indicated on terminal block and tighten terminal screws. Be sure to connect PE protective conductor (⊕) first.

- ⊕ → Ground (yellow-green)
- L → LINE (brown or black)
- N → Neutral (blue)



5. Make sure the wires are securely connected.

Caution: Important!!

Be sure to connect AC wires with correct polarity. If L and N wires are connected reversely, it may cause utility short-circuited when these inverters are worked in parallel operation.

Caution:

Appliances such as air conditioner are required at least 2~3 minutes to restart because it's required to have enough time to balance refrigerant gas inside of circuits. If a power shortage occurs and recovers in a short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check manufacturer of air conditioner if it's equipped with time-delay function before installation. Otherwise, this inverter/charger will trig overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner.

5.6 PV CONNECTION

Caution:

Before connecting to PV modules, please install separately a DC circuit breaker between inverter and PV modules.

Warning!

All wiring must be performed by a qualified personnel.

Warning!

It's very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommended cable size as below.

| Model | Wire size | Cable (mm ²) | Torque value (max) |
|-----------------|-----------|--------------------------|--------------------|
| PDA5500-STATION | 1*12AWG | 4 | 1.2Nm |

PV Module selection:

When selecting proper PV modules, please be sure to consider below parameters:

1. Open circuit Voltage (Voc) of PV modules not exceeds max. PV array open circuit voltage of inverter.
2. Open circuit Voltage (Voc) of PV modules should be higher than min. battery voltage.



| Inverter model | PDA5500-STATION |
|------------------------------------|-----------------|
| Max. PV Array Open Circuit Voltage | 500Vdc |
| PV Array MPPT Voltage Range | 120Vdc~450Vdc |

Take 250Wp PV module as an example. After considering above two parameters, the recommended module configurations are listed as below table.

| | Solar Input (Min in serial: 6 pcs, max. in serial: 13 pcs) | Q'ty of panels | Total input power |
|--|--|----------------|----------------------|
| Solar Panel Spec. (reference) - 250Wp - Vmp: 30.1Vdc - Imp: 8.3A - Voc: 37.7Vdc - Isc: 8.4A - Cells: 60 | 6 pcs in serial | 6 pcs | 1500W |
| | 8 pcs in serial | 8 pcs | 2000W |
| | 12 pcs in serial | 12 pcs | 3000W |
| | 13 pcs in serial | 13 pcs | 3250W |
| | 8 pieces in serial and 2 sets in parallel | 16 pcs | 4000W |
| | 10 pieces in serial and 2 sets in parallel | 20 pcs | 5000W |

Please follow below steps to implement PV module connection:


1. Remove insulation sleeve 10mm for positive and negative conductors.
2. Check correct polarity of connection cable from PV modules an PV input connectors. Then, connect positive pole (+) of connection cable to positive pole (+) of PV input connector. Connect negative pole (-) of connection cable to negative pole (-) of PV input connector.



3. Make sure the wires are securely connected.

5.7.Final Assembly


After connecting all wirings, please put bottom cover back by screwing two screws as shown below.



6. OPERATION


6.1 Power ON/OFF

Once the unit has been properly installed and the batteries are connected well, simply press ON/OFF switch (located on the button of the case) to turn on the unit.



6.2 Operation and Display panel

The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes three indicators, four function keys and a LCD display, indicating the operating status and input/output power information.




LED Indicator

| Led indicator | | Messages | |
|---------------|-------|----------|---|
| ☀ AC / ⚡ INV | Green | Solid ON | Output is powered by utility in Line mode. |
| | | Flashing | Output is powered by battery or PV in battery mode. |
| ☀ CHG | Green | Solid ON | Battery is fully charged. |
| | | Flashing | Battery is charging. |
| ⚠ FAULT | Red | Solid ON | Fault occurs in the inverter . |
| | | Flashing | Warning condition occurs in the inverter. |

Function KEYS

| Function Key | Description |
|--------------|---|
| ESC | To exit setting mode. |
| UP | To go to previous selection. |
| DOWN | To go to next selection. |
| ENTER | To confirm the selection in setting mode or enter setting mode. |

6.3 LCD Display Icons



| Icon | | Function description |
|---|---------------------|--|
| Input source information | | |
| | | Indicates the AC input. |
| | | Indicates the PV input. |
| | | Indicate input voltage, input frequency, PV voltage, battery voltage and charging current. |
| Configuration program and fault information | | |
| | | Indicates the setting programs. |
| | | Indicates the warning and fault codes. Warning: flashing with warning code. Fault: lighting with fault code. |
| Output information | | |
| | | Indicate output voltage, output frequency, load percent, load in VA, load in Watt and discharging current. |
| Battery information | | |
| | | Indicates battery level by 0-24%, 25-49%, 50-74% and 75-100% in battery mode and charging status in line mode. |
| In AC mode, it will present battery charging status. | | |
| Status | Battery voltage | LCD Display |
| Constant current mode / Constant voltage mode | <2V/cell | 4 bars will flash in turns. |
| | 2 ~ 2.083V/cell | Bottom bar will be on and the other three bars will flash in turns. |
| | 2.083 ~ 2.167V/cell | Bottom two bars will be on and the other two bars will flash in turns. |
| | 2.167V/cell | Bottom three bars will be on and the top bar will flash. |
| Floating mode. Batteries are fully charged. | | 4 bars will be on. |

| In battery mode, it will present battery capacity. | | |
|--|--------------------------|-------------|
| Load percentage | Battery voltage | LCD Display |
| Load > 50% | < 1.717V/cell | |
| | 1.717V/cell ~ 1.8V/cell | |
| | 1.8 ~ 1.883V /cell | |
| | > 1.883 V /cell | |
| 50% > Load > 20% | < 1.817V/cell | |
| | 1.817V/cell ~ 1.9V/cell | |
| | 1.9 ~ 1.983V/cell | |
| | > 1.983 | |
| Load < 20% | < 1.867V /cell | |
| | 1.867V/cell ~ 1.95V/cell | |
| | 1.95 ~ 2.033V/cell | |
| | > 2.033 | |

| Load information | | | | |
|---------------------|--|---------|---------|----------|
| | Indicates overload. | | | |
| 100% 25% | Indicates the load level by 0-24%, 25-50%, 50-74% and 75-100%. | | | |
| | 0%~25% | 25%~50% | 50%~75% | 75%~100% |
| | | | | |

| Mode operation information | |
|----------------------------|---|
| | Indicates unit connects to the mains. |
| | Indicates unit connects to the PV panel. |
| | Indicates load is supplied by utility power. |
| | Indicates the utility charger circuit is working. |
| | Indicates the DC/AC inverter circuit is working. |
| Mute operation | |
| | Indicates unit alarm is disabled. |

6.4 LCD Settings

After pressing and holding ENTER button for 3 seconds, the unit will enter setting mode. Press "UP" or "DOWN" button to select setting programs. And then, press "ENTER" button to confirm the selection or ESC button to exit.

| Setting Programs | | | |
|------------------|---|---|---|
| Program | Description | Selectable option | |
| 00 | Exit setting mode | Escape 00 ESC | |
| 01 | Output source priority: To configure load power source priority | 01 SUB | Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, utility energy will supply power to the loads at the same time. |
| | | 01 SUBU | Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, battery energy will supply power to the loads at the same time. Utility provides power to the loads only when battery voltage drops to either low-level warning voltage or the setting point in program 12. |
| 02 | Maximum charging current To configure total charging current for solar and utility chargers. (Max. charging current = utility charging current + solar charging current) | 10A 02 10 A | 20A 02 20 A |
| | | 40A 02 40 A | 50A 02 50 A |
| | | 70A 02 70 A | 80A 02 80 A |
| | | 100A 02 100 A | 110A 02 110 A |
| 03 | AC input voltage range | Appliances (default) 03 APL | If selected, acceptable AC input voltage range will be within 90-280VAC. |
| | | UPS 03 UPS | If selected, acceptable AC input voltage range will be within 170-280VAC. |
| 04 | Power saving mode enable/disable | Saving mode disable (default) 04 SDS | If disabled, no matter connected load is low or high, the on/off status of inverter output will not be effected. |
| | | Saving mode enable 04 SEN | If enabled, the output of inverter will be off when connected load is pretty low or not detected. |

Setting Programs

| Program | Description | Selectable option | | |
|---------|---|-------------------------------------|--|------------------------------|
| 05 | Battery type | AGM (default) 05 AGM | Flooded 05 FLD | |
| | | User-Defined 05 USE | If "User-Defined" is selected, battery charge voltage and low DC cut-off voltage can be set up in program 26, 27 and 29. | |
| 06 | Auto restart when overload occurs | Restart disable (default) 06 LTD | Restart enable 06 LTE | |
| 07 | Auto restart when over temperature occurs | Restart disable (default) 07 LTD | Restart enable 07 LTE | |
| 09 | Output frequency | 50Hz (default) 09 50 Hz | 60Hz 09 60 Hz | |
| 11 | Maximum utility charging current. | 2A 11 2A | 10A 11 10A | 20A 11 20A |
| | | 30A (default) 11 30A | 40A 11 40A | 50A 11 50A |
| | | 60A 11 60A | 70A 11 70A | 80A 11 80A |
| 12 | Setting voltage point back to utility source when selecting "SBU priority". | 44V 12 BATT 44v | 45V 12 BATT 45v | 46V (default) 12 BATT 46v |
| | | 47V 12 BATT 47v | 48V 12 BATT 48v | 49V 12 BATT 49v |
| | | 50V 12 BATT 50v | 51V 12 BATT 51v | |

Setting Programs

| Program | Description | Selectable option | | |
|---------|---|--|--|---|
| 13 | Setting voltage point back to battery mode when selecting "SBU priority". | Battery fully charged 13 BATT FUL | 48V 13 BATT 480 ^v | 49V 13 BATT 490 ^v |
| | | 50V 13 BATT 500 ^v | 51V 13 BATT 510 ^v | 52V 13 BATT 520 ^v |
| | | 53V 13 BATT 530 ^v | 54V (default) 13 BATT 540 ^v | 55V 13 BATT 550 ^v |
| | | 56V 13 BATT 560 ^v | 57 13 BATT 570 ^v | 58V 13 BATT 580 ^v |
| 16 | Charger source priority: To configure charger source priority | If this inverter/charger is working in Line, Stand by or Fault mode, charger source can be programmed as below: | | |
| | | Solar first 16 CSO | Solar energy will charge battery as first priority. Utility will charge battery only when solar energy is not available. | |
| | | Solar and Utility 16 SNU | Solar energy and utility will charge battery at the same time. | |
| | | Only Solar 16 OSO | Solar energy will be the only charger source no matter utility is available or not. | |
| | | If this inverter/charger is working in Battery mode or Power saving mode, only solar energy can charge battery. Solar energy will charge battery if it's available and sufficient. | | |
| 18 | Alarm control | Alarm on (default) 18 6ON | Alarm off 18 6OF | |
| 19 | Auto return to default display screen | Return to default display screen (default) 19 ESP | If selected, no matter how users switch display screen, it will automatically return to default display screen (Input voltage / output voltage) after no button is pressed for 1 minute. | |
| | | Stay at latest screen 19 TEP | If selected, the display screen will stay at latest screen user finally switches. | |

Setting Programs

| Program | Description | Selectable option | |
|---------|--|--|--|
| 20 | Backlight control | Backlight on (default) 20 LON | Backlight off 20 LOF |
| 22 | Beeps while primary source is interrupted | Alarm on (default) 22 AON | Alarm off 22 AOF |
| 23 | Overload bypass: When enabled, the unit will transfer to line mode if overload occurs in battery mode. | Bypass disable (default) 23 bYd | Bypass enable 23 bYE |
| 25 | Record fault code | Record enable 25 FEN | Record disable (default) 25 FdS |
| 26 | Bulk charging voltage (C.V voltage) | Default setting: 56.4V CU 26 ^{BATT} 56.4V | |
| | | If self-defined is selected in program 5, this program can be set up. Setting range is from 48.0V to 58.4V. Increment of each click is 0.1V. | |
| 27 | Floating charging voltage | Default setting: 54.0V FLU 27 ^{BATT} 54.0V | |
| | | If self-defined is selected in program 5, this program can be set up. Setting range is from 48.0V to 58.4V. Increment of each click is 0.1V. | |
| 29 | Low DC cut-off voltage | Default setting: 42.0V COU 29 ^{BATT} 42.0V | |
| | | If self-defined is selected in program 5, this program can be set up. Setting range is from 40.0V to 48.0V. Increment of each click is 0.1V. Low DC cut-off voltage will be fixed to setting value no matter what percentage of load is connected. | |
| 31 | Solar power balance: When enabled, solar input power will be automatically adjusted according to connected load power | Solar power balance: enable (default): 31 56E | If selected, solar input power will be automatically adjusted according to the following formula: Max. input solar power = Max. battery charging power + Connected load power. |









6.5 Display Settings










The LCD display information will be switched in turns by pressing "UP" or "DOWN" key. The selectable information is switched as below order: input voltage, input frequency, PV voltage, MPPT charging current, MPPT charging power, battery voltage, output voltage, output frequency, load percentage, load in Watt, load in VA, load in Watt, DC discharging current, main CPU Version and second CPU Version.

| Selectable information | LCD display |
|--|--|
| Input voltage/Output voltage (Default Display Screen) | <p>Input Voltage=230V, output voltage=230V</p> |
| Input frequency | <p>Input frequency=50Hz</p> |
| PV voltage | <p>PV voltage=360V</p> |
| MPPT Charging current | <p>Current ≥ 10</p> <p>Current < 10</p> |
| MPPT Charging power | <p>MPPT charging power=500W</p> |
| Battery voltage/DC discharging current | <p>Battery voltage=25.5V, discharging current=1A</p> |


















| Selectable information | LCD display |
|---------------------------|--|
| Output frequency | <p>Output frequency = 50Hz</p> |
| Load percentage | <p>Load percent = 70%</p> |
| Load in VA | <p>When connected load is lower than 1kVA, load in VA will present xxxVA like below chart.</p> <p>When load is larger than 1kVA, load in VA will present x.xkVA like below chart.</p> |
| Load in Watt | <p>When load is lower than 1kW, load in W will present xxxW like below chart.</p> <p>When load is larger than 1kW (≥ 1 kW), load in W will present x.xkW like below chart.</p> |
| Main CPU version checking | <p>Main CPU version 00014.04.</p> |

6.6 Operating mode description











| Operation mode | Description | LCD display |
|---|---|---|
| <p>Standby mode / Power saving mode</p> <p>Note:</p> <ul style="list-style-type: none"> * Standby mode: The inverter is not turned on yet but at this time, the inverter can charge battery without AC output. * Power saving mode: If enabled, the output of inverter will be off when connected load is pretty low or not detected. | <p>No output is supplied by the unit but it still can charge batteries.</p> | <p>Charging by utility and PV energy.</p>  |
| | | <p>Charging by utility.</p>  |
| | | <p>Charging by PV energy.</p>  |
| | | <p>No charging.</p>  |
| <p>Fault mode</p> <p>Note:</p> <ul style="list-style-type: none"> * Fault mode: Errors are caused by inside circuit error or external reasons such as over temperature, output short circuited and so on. | <p>PV energy and utility can charge batteries.</p> | <p>Charging by utility and PV energy.</p>  |
| | | <p>Charging by utility.</p>  |
| | | <p>Charging by PV energy.</p>  |
| | | <p>No charging</p>  |

| Operation mode | Description | LCD display |
|----------------|--|---|
| Line Mode | The unit will provide output power from the mains. It will also charge the battery at line mode. | Charging by utility and PV energy.  |
| | | Charging by utility  |
| | | If "SUB" is selected as output source priority and solar energy is not sufficient to provide the load, solar energy and the utility will provide the loads and charge the battery at the same time.  |
| | | If "SUB" is selected as output source priority and battery is not connected, solar energy and the utility will provide the loads.  |
| | | Power from utility.  |
| Battery mode | The unit will provide output power from battery and PV power. | Power from battery and PV energy.  |
| | | PV energy will supply power to the loads and charge battery at the same time.  |
| | | Power from battery only.  |
| | | Power from PV energy only.  |

6.7 Fault reference code

| Fault code | Fault Event | Icon on |
|------------|--|---|
| 01 | Fan is locked when inverter is off. |  |
| 02 | Over temperature. |  |
| 03 | Battery voltage is too high. |  |
| 04 | Battery voltage is too low. |  |
| 05 | Output short circuited or over temperature is detected by internal converter components. |  |
| 06 | Output voltage is too high. |  |
| 07 | Overload time out. |  |
| 08 | Bus voltage is too high. |  |
| 09 | Bus soft start failed. |  |
| 11 | Main relay failed. |  |
| 51 | Over current or surge. |  |
| 52 | Bus voltage is too low. |  |
| 53 | Inverter soft start failed. |  |
| 55 | Over DC voltage in AC output. |  |
| 56 | Battery connection is open |  |
| 57 | Current sensor failed. |  |
| 58 | Output voltage is too low. |  |

6.8 Warning indicator

| Warning code | Warning event | Audible alarm | Icon flashing |
|--------------|---|--------------------------------|---|
| 01 | Fan is locked when inverter is ON. | Beep three times every second. |  |
| 03 | Battery is over-charged. | Beep once every second. |  |
| 04 | Low battery. | Beep once every second. |  |
| 07 | Overload. | Beep once every 0.5 second. |  |
| 10 | Output power derating. | Beep twice every 3 seconds. |  |
| 12 | Solar charger stops due to low battery. | |  |
| 13 | Solar charger stops due to high PV voltage. | |  |
| 14 | Solar charger stops due to overload. | |  |
| 15 | PV is weak | |  |
| 19 | Battery is not connected | |  |

7. SPECIFICATIONS

Table 1 - Line mode specifications

| Inverter model | PDA5500-STATION |
|---|---|
| Input voltage waveform | Sinusoidal (utility or generator) |
| Nominal input voltage | 230Vac |
| Low loss voltage | 170Vac \pm 7V (UPS); 90Vac \pm 7V (Appliances) |
| Low loss return voltage | 180Vac \pm 7V (UPS); 100Vac \pm 7V (Appliances) |
| High loss voltage | 280Vac \pm 7V |
| High loss return voltage | 270Vac \pm 7V |
| Max AC input voltage | 300Vac |
| Nominal input frequency | 50Hz / 60Hz (Auto detection) |
| Low loss frequency | 40 \pm 1Hz |
| Low loss return frequency | 42 \pm 1Hz |
| High loss frequency | 65 \pm 1Hz |
| High loss return frequency | 63 \pm 1Hz |
| Output short circuit protection | Line mode: Circuit breaker Battery mode: Electronic circuits |
| Efficiency (Line mode) | 95% (Rated R load, battery full charged) |
| Transfer time | 10ms typical (UPS); 20ms typical (Appliances) |
| Output power derating: When AC input voltage drops 170V, the output power will be derated. | <p>The graph plots Output power against Input voltage. The x-axis is labeled 'Input voltage' and has markers at 90V, 170V, and 280V. The y-axis is labeled 'Output power' and has markers for '50% power' and 'Rated power'. The graph shows that for input voltages between 170V and 280V, the output power is constant at the 'Rated power' level. As the input voltage drops below 170V, the output power is derated linearly, reaching '50% power' at 90V. At 280V, the output power drops to zero.</p> |

Table 2 - Inverter mode specifications

| Inverter model | PDA5500-STATION |
|-------------------------------|--|
| Rated output power | 5.5KVA/5.5KW |
| Output voltage waveform | Pure Sine Wave |
| Output voltage regulation | 230Vac \pm 5% |
| Output frequency | 60Hz or 50Hz |
| Peak efficiency | 94% |
| Overload protection | 5s@ \geq 150% load; 10s@110%~150% load |
| Surge capacity | 2* rated power for 5 seconds |
| Nominal DC input voltage | 48.0Vdc |
| Cold start voltage | 46.0Vdc |
| Low DC Warning voltage | |
| @load < 20% | 44.0Vdc |
| @20% \leq load < 50% | 42.8Vdc |
| @load \geq 50% | 40.4Vdc |
| Low DC Warning return voltage | |
| @load < 20% | 42.0Vdc |
| @20% \leq load < 50% | 40.8Vdc |
| @load \geq 50% | 38.4Vdc |
| High DC recovery voltage | 58.0Vdc |
| High DC cut-off voltage | 62Vdc |
| No load power consumption | < 50W |
| Saving mode power consumption | < 15W |

Table 3 - Inverter mode specifications

| Inverter model | | PDA5500-STATION |
|---|-------------------|---|
| Charging Current (UPS) @ Nominal Input Voltage | | 80A |
| Bulk charging voltage | Flooded battery | 58.4 |
| | AGM / Gel battery | 56.4 |
| Floating charging voltage | | 54Vdc |
| Charging algorithm | | 3-step |
| Charging curve | | <p>The graph illustrates the charging curve for the PDA5500-STATION. The left y-axis represents 'Battery voltage, per cell' with values 2.25Vdc and 2.43Vdc (2.35Vdc). The right y-axis represents 'Chargin current, %' with values 50% and 100%. The x-axis is 'Time'. The curve is divided into three stages: BULK (constant current), ABSORPTION (constant voltage), and MAINTENANCE (floating). The BULK stage shows a linear increase in voltage from 2.25Vdc to 2.43Vdc. The ABSORPTION stage shows a constant voltage of 2.43Vdc while the current decreases. The MAINTENANCE stage shows a constant voltage of 2.25Vdc. Time intervals T0, T1, and T2 are marked. T2 = 10 * T0, minimum 10mins, maximum 8hrs.</p> |

| Solar Charging Mode | |
|------------------------------------|------------|
| Rated power | 6000W |
| PV charge current | 110A |
| Efficiency | 98.0% max. |
| Max. PV Array open circuit voltage | 500Vdc |
| PV Array MPPT voltage range | 120-450Vdc |
| Standby power consumption | 2W |
| Battery voltage accuracy | +/-0.3% |
| PV voltage accuracy | +/-2V |
| Charging algorithm | 3-step |

Table 4 - General specifications

| Inverter model | PDA5500-STATION |
|-----------------------------|-----------------|
| Safety certification | CE |
| Operating temperature range | 0°C to 55°C |
| Storage temperature | -15°C~60°C |
| Dimension (D*W*H), mm | 472*297*133 |
| Net weight, kg | 10.7 |

8. TROUBLE SHOOTING

| Problem | LCD / LED / Buzzer | Explanation /Possible cause | What to do |
|---|---|---|---|
| Unit shuts down automatically during startup process. | LCD/LEDs and buzzer will be active for 3 seconds and then complete off. | The battery voltage is too low (<1.91V/Cell) | 1. Re-charge battery. 2. Replace battery. |
| No response after power on. | No indication. | 1. The battery voltage is far too low. (<1.4V/Cell) 2. Battery polarity is connected reversed. | 1. Check if batteries and the wiring are connected well. 2. Re-charge battery. 3. Replace battery. |
| Mains exist but the unit works in battery mode. | Input voltage is displayed as 0 on the LCD and green LED is flashing. | Input protector is tripped . | Check if AC breaker is tripped and AC wiring is connected well. |
| | Green LED is flashing. | Insufficient quality of AC power. (Shore or Generator). | 1. Check if AC wires are too thin and/or too long. 2 Check if generator (if applied) is working well or if input voltage range setting is correct. (UPS → Appliance) |
| | Green LED is flashing. | Set "Solar First" as the priority of outout source. | Change output source priority to Utility first. |
| When the unit is turned on, internal relay is switched on and off repeatedly. | LCD display and LEDs are flashing. | Battery is disconnected. | Check if battery wires are connected well. |
| Buzzer beeps continuously and red LED is on. | Fault code 07. | Overload error. The inverter is overload 110% and time is up. | Reduce the connected load by switching off some equipment. |
| | Fault code 05. | Output short circuited. | Check if wiring is connected well an remove abnormal load. |
| | | Temperature of internal converter component is over 120°C. | Check whether the air flow of the unit is blocked or whether the ambient temperature is too high. |
| | Fault code 02. | Internal temperature of inverter component is over 100°C. | |
| | Fault code 03. | Battery is over-charged. | Return to repair center. |
| | | The battery voltage is too high. | Check if spec and quantity of batteries are meet requirements. |
| | Fault code 01. | Fan fault. | Replace the fan. |
| | Fault code 06/58. | Output abnormal (inverter voltage below than 190Vac or is higher than 260VAC). | 1. Reduce the connected load. 2. Return to reocair center. |
| | Fault code 08/09/53/57. | Internal components failed. | Return to repair center. |
| | Fault code 51. | Over current or surge. | Restart the unit, if the error happens again, please return to repair center. |
| | Fault code 52. | Bus voltage is too low. | |
| | Fault code 55. | Output voltage is unbalanced. | |
| Fault code 56. | Battery is not connected well or fuse is burnt. | If the battery is connected well, please return to repair center. | |

9. APPENDIX: Approximate Back-up Time Table

| Model | Load (W) | Backup Time @ 48Vdc 100Ah (min) | Backup Time @ 48Vdc 200Ah (min) |
|-----------------------|----------|---------------------------------|---------------------------------|
| PDA1500-STATION (12V) | 500 | 613 | 1288 |
| | 1000 | 268 | 613 |
| | 1500 | 158 | 402 |
| | 2000 | 111 | 271 |
| | 2500 | 90 | 215 |
| | 3200 | 76 | 182 |
| | 3500 | 65 | 141 |
| | 4000 | 50 | 112 |
| | 4500 | 44 | 100 |
| | 5000 | 40 | 90 |

Note: Backup time depends on the quality of the battery, age of battery and type of battery. Specifications of batteries may vary depending on different manufacturers.

fullwat.com



Agente importador
A48.139.786
UKAI S.A.
Ribera de Elorrieta, 7C
48015 - Bilbao - SPAIN
Designed in EU - Made in PRC